





CABINET PARTS

For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)

REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	LIT2220018	Use & Care Guide
	LIT2216342	Service & Wiring Sheet
	LIT2219949	Energy Label
	LIT628370	Modular Icemaker Service Sheet
2	2174748	Front Roller (2)
3	3400517	Screw
4	2196236	Roller (Rear) (2)
5	489427	Screw
6	2155013	Clip, Grille
7	489478	Screw
8	2186443	Housing, Water Filter
9	2156056	Shim
10	489500	Screw
11	2203220	Water Filter
12	2203770	Hinge Top (FC)
13	2203771	Hinge, Top (RC)
14	488500	Screw
15		Hinge Cover
	2203407W	White
	2203407T	Biscuit
	2203407B	Black
16	2217075	Hinge Bottom (2)
17		Cap, Water Filter
	2186494W	White
	2186494T	Biscuit
	2186494B	Black
21		Filler, Wrapper
	2196094	White
	2196150	Biscuit
	2196097	Black
22		Grille
	2198468W	White
	2198468T	Biscuit
	2198468B	Black
23	489497	Screw
35	489464	Screw
41	940139	Drain Fitting
42	1108438	Extension Tube
43	1108439	Clip, Drain Tube
47	2204203	Cover, Unit
48		Cabinet (Not A Serviceable Part)
49		Hinge Cover
	2203408W	White
	2203408T	Biscuit
	2203408B	Black
50	8281227	Screw
52	549193	Clamp, Service Cord
53	489084	Screw
54	2155311	Door Closer, Lower Cam (2)
55	489483	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2194744	Escutcheon, Meat Pan Control
3	2182757	Slide, Meat Pan Control
4	2182147	Louver
8	2196483	Stud Assembly (4)
9	8281158	Screw
11	489290	Screw (2)
13	2206273	Shelf Ladder
14	487539	Screw
22	1123919	Bracket Retainer
24	2209753	Air Diffuser Assembly
25	2152019	Air Diffuser Cover
26	2150331	Cover, Conduit
27	486298	Screw
29	2162085	Socket
31	2217199	Reservoir
33	527949	Light Bulb
34	2206269	Light Lens
35	2205813	Strap
37	488280	Screw (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS


For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02

(White)

(Biscuit)

(Black)


Illus. No.	Part No.	DESCRIPTION
1	2194281	Shelf, Cantilever (2)
2	2174150	Glass, Cover
3	2209698	Cover, Crisper
4	2194913	Trim, Pan
5	2179259	Glass, Cover
6	2179350	Deflector
7	2194906	Trim, Meat Pan
8	2217039	Cover, Meat Pan
9	2179342	Slide, Humidity (Control)
10	2196232	Crisper Pan
11	2196231	Meat Pan
13	2179243	Trim, Snack Pan
14	2179343	Housing, Humidity (Control)
15	2206347	Shelf, Snack Bin
18	2196233	Snack Bin
20	2196483	Stud Assembly
21	2196485	Stud Assembly
22	3400894	Screw
23	8281158	Screw



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS


For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2209674	Bracket, Fill Tube
3	2171713	Door, Ice Compartment
6	842534	Clip, Air Duct (2)
7	2196206	Support, Stud (4)
10	2176134	Grommet
11	2182971	Freezer Bin
14	2155572	Wiring Cover
15	489355	Screw
17		Slide, Basket
	2181760	Right Side
	2181759	Left Side
18	486298	Screw
19	1115373	Switch, Rocker Arm
20	8281158	Screw
21	2196483	Stud Assembly
23	2171714	Shelf, Top Compartment
24	2171705	Light Lens
25	527949	Light Bulb
26	2162085	Light Socket
27	2196207	Stud, Rear
28		Slide, Container
	1119237	Left Side
	1119293	Right Side
29	489100	Screw
30	3400893	Screw
31	2174268	Shelf (2)
	2174267	Shelf (1)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS


For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	2183726	Bracket, Motor
2	2188385	Motor, Dispenser
3	2152713	Solenoid Assembly
4	2149100	Guide, Solenoid
6	1115374	Clip, Wiring
7	2206501	Wiring Assembly, Ice Dispenser
8	489399	Screw
9	2205716	Coupling, Motor
10	489478	Screw
11	2162085	Socket, Light
14	2196091	Ice Container
18	1119005	Spacer, Step (3)
19	1119007	Spacer, Flat (2)
20	1119006	Blade, Rotary
21	1119012	Blade, Rotary
22	1119013	Blade, Rotary
23	489235	Washer, Plain
24	1119009	Blade, Fixed (2)
25	2157405	Block, Blade
26	489229	Roll Pin
27	2196295	Auger
28	2209781	Drum
30	2171682	Floating Baffle
31	1119018	Nut, Bearing
32	2155231	Control Arm
33	1119020	Spring, Return
34	1119021	Retainer Clip, Rod
35	488886	Screw
37	2180348	Housing, Crusher
38	1119017	Deflector, Ice
39	489234	Washer, Plain
40	489236	Retainer Ring
44	2204321	Front Cover, Ice Container
45	527949	Light Bulb
46	2171706	Light Lens, Dispenser

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Item 6)
	2206682W	White
	2206682T	Biscuit
	2206682B	Black
2	2177105	Door, Compartment
3	489491	Screw
4	2203828	Shelf Bin (3)
5		Extension, Handle
	2194969W	White
	2194969T	Biscuit
	2194969B	Black
6		Door Gasket, Magnetic
	2196243	Mist Beige
	2196241	Black
7		Handle, Center
	2186649W	White
	2186649T	Biscuit
	2186649B	Black
8	2182180	Thimble—Top
9	2195327	Clip (4)
10		Extension, Handle
	2194973W	White
	2194973T	Biscuit
	2194973B	Black
11	2182178	Door Closer, Upper Cam
12	489420	Screw
13		Bracket, Door Stop
	2206629	Chrome
	2206629B	Black
19	3400852	Screw
22	2156022	Trivet, Shelf
23	3400012	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)

This exploded view diagram illustrates the assembly of a refrigerator door. The central component is the door body (1), which features internal shelves (11) and a handle (2). The door is shown in its open position, revealing the internal structure and the door's profile. The diagram includes the following numbered components:

- 1**: The main door body.
- 2**: The door handle.
- 3**: A screw used for mounting the door to the frame.
- 4**: A small plastic clip or spacer.
- 5**: A small metal pin or screw.
- 6**: A small metal bracket or clip.
- 7**: A small metal pin or screw.
- 8**: The refrigerator frame or cabinet.
- 9**: A small metal bracket or clip.
- 10**: A small metal pin or screw.
- 11**: The internal shelves of the door.
- 12**: A small metal pin or screw.
- 13**: A small metal pin or screw.
- 14**: A small metal pin or screw.
- 17**: A long vertical metal strip or frame component.
- 18**: A long vertical metal strip or frame component.
- 22**: A small metal pin or screw.
- 23**: A small metal pin or screw.

11

FREEZER DOOR PARTS


For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes Item 8 And Dispenser Front Parts)
	2216318W	White
	2216318T	Biscuit
	2216318B	Black
2		Handle, Center
	2186649W	White
	2186649T	Biscuit
	2186649B	Black
3	2182181	Thimble-Top
4	489491	Screw
5	2195327	Clip (4)
6	2171157	Trivet, Shelf (4)
7	3400012	Screw
8		Door Gasket, Magnetic
	2196244	Mist Beige
	2196242	Black
9	2209681	Trim, Door Shelf
10	488500	Screw
11	2206601	Wire Harness
12	2182179	Door Closer, Upper Cam
13	489420	Screw
14		Bracket, Door Stop
	2206629	Chrome
	2206629B	Black
17		Extension, Handle
	2194969W	White
	2194969T	Biscuit
	2194969B	Black
18		Extension, Handle
	2194973W	White
	2194973T	Biscuit
	2194973B	Black
22	3400852	Screw
23	2154473	Connector

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS

For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS


For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	3196165	Screw
3	2194719	Retainer, Levers
4	2180209	Spring, Torsion
5	2196195	Pin
6	2180352	Door, Ice
7	2206423	Door Mechanism Assembly
8	2205686	Mechanism Delay
9		Grille, Overflow
	2206670W	White
	2206670T	Biscuit
	2206670B	Black
10	2209718	Water Fitting Assembly (Includes Water Tube)
11		Lever, Ice Dispenser
	2195089W	White
	2195089T	Biscuit
	2195089B	Black
12	2180224	Guide, Ice
13	2180200	Lamp Holder
14	2162361	Switch (2)
15	2183771	Bracket, Control
16	3406124	Bulb, Light
17		Lever, Water Dispenser
	2195090W	White
	2195090T	Biscuit
	2195090B	Black
18		Switch Assembly (Not Available Order #23)
19		Overlay, Front Cover (Not Available Order #23)
20	2187408	Wire Assembly
21		Front Cover, Housing (Not Available, Order #23)
22	489000	Screw
23		Front Cover Assembly (Includes Items 18, 19, 20 & 21)
	2207265W	White
	2207265T	Biscuit
	2207265B	Black
24	625834	Spacer, Switch (2)
25	2195051	Strain Relief

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	486692	Speed Nut
2	2190685	Fan, Blade
3	2204484	Condenser Assembly
4	489464	Screw
5	2208280	Clip, Wire
6	489099	Screw
8	2161302	Sleeve
9	2158826	Dampener
12	4387731	Cover
13	4387835	Overload (Service Compressor Only, Includes Relay)
14	2204239	Tube Suction
15	2216914	Clip, Condenser
16	2216697	Start Device, Combination (Start Relay and Overload for Production Compressor only)
17	4387764	Capacitor (Service)
18	2211760	Tube, Condenser to Heat Loop
21	489478	Screw
22	2209611	Evaporator
23	2161324	Clamp
24	2188537	Fan, Motor
25	1105523	Tray, Evaporator
26	2149294	Heat Shield
27	2199167	Drier

Illus. No.	Part No.	DESCRIPTION
28	2212192	Compressor (Includes Items 12, 13, 16, 17, 27) (Also Order 876765 Tube Kit)
30	2157397	Unit Mounting Frame
31	2187397	Unit, Harness (Includes Power Cord)
32	2181929	Fan, Motor Bracket
33	2188175	Heater, Defrost
34	2161330	Clip
35	2196155	Bi-Metal, Defrost
37	489473	Screw
39	2183042	Grommet (4) (Production)
	4387558	(Service)
40	489340	Screw
41	2196202	Air Baffle
42	2155547	Clip, Heat Shield
43	2206281	Unit Cover, Bottom
44	489396	Clip
48	1127911	Unit Mounting Rail
49	489415	Screw
50	2186495	Guard, Fan
52	2172840	Strap
53	489427	Screw
54	227991	Wire Connector
63	2209709	Union

Illus. No.	Part No.	DESCRIPTION
Following Parts Not Illustrated and Optional Parts Not Included		
	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978028	Valve, Access (1/2")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")

REFRIGERANT CHARGE


5.0 oz.
(R-134A)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AIR FLOW PARTS

For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)




Illus. No.	Part No.	DESCRIPTION
1	2182120	Fan Scroll
2	2155590	Retainer, Fan Motor
3	2161231	Air Scoop
5	2203593	Air Duct Freezer
7	2149299	Fan Motor
8	2169142	Fan Blade
10	2176759	Fan Grommet (2)
11	2182146	Duct, Icemaker
12	2206504	Harness, Fan Evaporator, And Heater, Bi-Metal
13	2155789	Gasket Cover
14	2172840	Wire Tie
16	2203876	Gasket
17	2203841	Cover, Evaporator
18	489355	Screw
21	489478	Screw
22	2203595	Support, R.S
23	2203596	Support, L.S

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PARTS

For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	2200137	Control Box
2	1110629	Mounting Bracket
3	3196537	Screw (4)
4	2149705	Light Switch
6	2188375	Defrost Timer (10 Hr.)
7	489398	Screw (2)
8	940014	Hole Plug
9	2198202	Thermostat
10	487869	Screw
11	2182195	Cam Assembly


Illus. No.	Part No.	DESCRIPTION
12	1110560	Bearing Body
14	2196062	Clip, Damper Control
15	1110559	Pivot Arm
16	627068	Screw
17	2162085	Light Socket
18	2196001	Thermostat, Barrier
19	527949	Light Bulb
20	2206512	Control Box Harness

Illus. No.	Part No.	DESCRIPTION
21	1115374	Clip, Wiring
22	1115375	Clip, Wiring
23	1123960	Connecting Rod
24	489285	Fastener, Push-On
25	2212074	Escutcheon, Control Box
26	2182111	Thermostat, Knob
27	2197871	Knob, Air Control
29	489203	Spring Washer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	2196157	Fitting, Water Tube
3	2186492	Tube, Filter Inlet
4	2186493	Tube, Filter Outlet
5	628379	Clip, Fuse
7	2181940	Tube, Water
9	489478	Screw
10	2205762	Valve, Solenoid
11	627018	Nut, Compression
14	489385	Tube Clamp
18	2174155	Cover
19	488649	Screw
20	628228	Mold & Heater Assembly (Also Order 542638
22	628356	Cup, Water Fill
23	2194711	Ejector
24	2182124	Ice Striper
25	2194712	Support
26	627796	Retainer, Thermostat
27	628397	Thermostat (Also Order 542369 Cement Alumilastic)
28	489322	Screw
30	489276	Screw
31	2171593	Shut Off Arm
32	628256	Harness, Wiring
33	628320	Bracket
35	628399	Module Assembly (Includes Items 37 & 38)
36	488208	Screw
37	628398	Motor
38	489136	Screw
40	1129179	Nut, Compression
100	4317943	Complete Ice maker Assembly

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

PARTS NOT ILLUSTRATED

For Models: ED5FHGXKQ02, ED5FHGXKT02, ED5FHGXKB02
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and Optional Parts (Not Included)			<u>Miscellaneous</u>			<u>Refinishing Material</u>		
<u>Customer Touch-Up Material</u>			212643		Sealer, Gum (4 Feet)	799340		Enamel, Black (1 Qt. Uncut)
*350942		Primer, White (13 Oz. Spray Can)	479502		Tape, Vinyl (3/4 x 108")	799344		Enamel, White (1 Qt. Uncut)
*350939		Enamel, Black (13 Oz. Spray Can)	876370		Kit, Insulation (2 Pcs. x 3" x 24" X 48")	978883		Enamel, Almond (1 Qt. Uncut)
*350930		Enamel, White (13 Oz. Spray Can)	876305		Kit, Insulation (14 Pcs. x 3" x 24" x 48")	<u>TORX SCREW WRENCH</u>		
*350956		Enamel, Almond (13 Oz. Spray Can)	978941		Insulation, Fiberglass (63-1/2" x 35-1/2" X 2-5/8)	1117510		Torx Key
72017		Brush Touch-Up Kit (White)	876029		Kit, Foam Slab (30" x 32-1/2" x 1-1/2")			
72107		Brush Touch-Up Kit (Almond)	505587		Sealer, Mastic (1 Qt.)			
72032		Brush Touch-up Kit (Black)	503695		Cork, Sealer (1/4 Pound)			
* Caution: The spray paint is not to be used where the paint may make contact with the door gaskets.			511873		Touch-Up, White Porcelain (2 Oz.)			
			542638		Grease, Silicone (1/2 Oz.)			
			542639		Cement, Alumilastic (1-1/4 Oz.)			
			606755		Bag, Insulation (36-5/8" x 46")			
			799833		Kit, Evaporator Repair (Aluminum Epoxy)			
			833938		Kit, Terminal Connector			
			2209780		Ice Container Assembly			
			2149072		Ice Crusher Mechanism Assembly			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST